Pitcher Rinser User Instructions

Universal instruction for all models



Tip left over heated milk into tray

Press Down 5sec



Leave cleaned jug on platform or tray

Clean each day

Pull platform disk up to remove and wash
Remove grill and wash
Wipe and rinse lower tray with hot water

Reassembling Rinser

Place grill back into lower tray
Place platform back onto valve, **DO NOT** push down
(The first use of the rinser with jug will position platform on valve)





Spare Parts List

ESPRESSOBITS™
QUALITY PARTS & ACCESSORIES







ITEM NO.	PART NUMBER	DESCRIPTION
1	PR001D-V2	PR LOWER VALVE BODY V2
2	PR015	FLAT LOCKING NUT 1/2F
3	PR001C	GASKET FLAT PLAIN 23 ID x 2 THK
4	PR001F-V2	PR VALVE SLEEVE V2
5	PR017-V2	SPINDLE RINSER VALVE V2
6	PR001A	O-RING HI-DENSITY TAP WASHER 5.5 ID x 2.5 DIA
7	PR001B	ORING 5 ID x 1.5 DIA
8	PR014A	SPRING RISER HD
9	PR001E-V2	PR MIDDLE VALVE BODY V2
10	PR002A	PR DRAIN / VALVE BODY ORING 14 ID x 2 DIA
11	PR016-V2	SPRAY HEAD RINSER V2
12	PR016A-V2	SPRAY HEAD NUT M16X4.5 V2
13	PR005	PLATFORM FOR PITCHER RINSER